



Page 3D For ScreenPlay & Sequel

2120 Las Palmas Road, Suite D
Carlsbad, CA 92009
760-931-6417 (general)
760-931-6971 (tech support)
www.applied-magic.com

INSTALLING PAGE 3D

1. Place the *version 2.5+ (or current version) ScreenPlay & Sequel* CD into the CD-ROM drive on the front of your ScreenPlay/Sequel.
2. Once the CD drawer closes, your ScreenPlay/Sequel will display a menu for installing *Software Updates & Extras*. Select/click on *Extras* and then select *Applied Magic Add-On's*.
3. Next select/click *Page 3D*. This is where you will install Page 3D and enter your activation code.
4. Once installed you can sample the functionality of Page 3D. To create a full frame Page 3D video you must purchase an activation code and enter it under *Activate Page 3D* Once activation is complete, cancel out of the Page and select/click on *Finish*.
5. Lastly, select *Restart* to reboot your unit; which is necessary for loading Page 3D.

GETTING STARTED WITH PAGE 3D

1. Go to Transitions and open the Page 3D folder.
2. Select any of the Page 3D Transitions and place it between two clips on your StoryBorad. Each transition icon indicates the style of the Page turn.
3. Page 3D transitions need to be Merged to be viewable upon playback. Unmerged transitions will flash an asterisk in the upper left corner of the screen. To Merge transitions, select the Page 3D transition on the StoryBorad and hit the Merge key on the keyboard or right click the mouse and select Merge. When the transition is fully Merged an asterisk will appear in the lower left corner of the transition.

PAGE 3D DETAILS

1. To view your Transition before merging, select the transition on the StoryBorad, go into details and scrub through the transition. In this section you can control the In and Out points of the transition and adjust the transition duration. For more information on this, see the details section of your ScreenPlay/Sequel manual.
2. Opaque Option- When this option is checked On the Page will have a white background on the page curl. If checked Off, you will see a reflection of the video image on the back of the Page.
3. Watermark Option- When this option is check On the Page will have the Applied Magic logo watermarked on the back of the Page.
4. Page Radius- Adjusting this will tighten or loosen the curl of your Page turn.
5. Page Angle- Adjusting this will change the direction the of your Page turn.
6. Transition Envelope- This section controls the Start and Finish of the transition. You can add new points to control the mix of the transition and alter the course of Start to Finish.